

Rubber Floor Maintenance Instructions

1. Instructions for use

(1) A carpet or floor mat shall be placed at the entrance and exit of rubber floor to prevent dust and silt from being brought in, so as to reduce the abrasion caused to the floor.

(2) In order to keep the rubber floor smooth and clean, it is best to wax the floor once every 3-5 months. At least 1-2 layers of wax shall be waxed for the first time, and 2-3 layers of wax may be waxed according to the situation during the maintenance period.

(3) At ordinary times, a large amount of water should not be used, especially hot water for dragging, so as not to cause dewaxing, degumming, fading and wing bending deformation.

(4) At ordinary times, some sharp metal tools, such as knives and scissors, shall not fall on the floor to avoid scratching the surface.

2. Significance and method of waxing rubber floor:

Waxing effect significance: can protect the floor surface, make it both beautiful and easy to clean. Improve the brightness of the ground, increase the ground texture, beautiful feeling, improve the working space environment, so that workers in a comfortable environment to work efficiently.

Method:

1. First, use dust pushing or vacuum cleaner to vacuumize to remove the surface garbage.
2. Use waxing water to dilute it at 1:10 and then evenly spread it on the ground. Wait for 5-10 minutes, and then add black strong waxing pad with a floor wiper to remove wax. Drain the sewage with the water suction machine in time.
3. Overwash with clean water and absorb it dry, and wash it repeatedly as appropriate until there is no residual wax and detergent left on the floor.